



**CHEM GUARD** INC.

بمركزها



# ISS EGY-CP2605 6% FLUOROPROTEIN FOAM CONCENTRATES

## Description

The ISS brand 6% Fluoroprotein foam concentrate, **EGY-CP2605**, is formulated from hydrolysed protein, fluorochemical surfactants, foam stabilizers (metal salts), bactericide, corrosion inhibitors, freezing point depressants and solvents. It is transported and stored as a concentrate to provide ease of use and considerable savings in weight and space.

It is intended for use as a 6% proportioned solution either in fresh, salt or hard water. The correct proportioning ratio is 6 parts of concentrate to 94 parts of water.

Two fire extinguishing mechanisms are in effect when using fluoroprotein foams. First, a foam blanket prevents the release of fuel vapor. Second, the water content of the foam provides a cooling effect.

## Typical Properties

Fire Classes	B
Shape and Colour	Brown, Clear Liquid
Smell	Characteristic, Protein
Density (20°C)	1.14 ± 0.02 g/ml
pH (Concentrate, 20°C)	6.0 – 8.0
Viscosity (20°C)	6.0 ± 4.0 mm <sup>2</sup> /s
Sediment	≤ 0.25%
Admixing ratio	6% Vol.
Expansion Ratio (EN 1568-3)	≥ 7.0
Drain Time 25%, (20°C, EN1568-3)	≥ 5:00
Drain Time 50%, (20°C, EN1568-3)	≥ 9:00
Expansion	Low, (Medium)
Freezing Point	≤ -15°C
Pour Point	≤ -12°C
Recommended Storage / Usage Temperature	-10 to +60° C

## Listings and Approval

**EGY-CP2605** is approved or listed according to:

- UL-162

## Application

**EGY-CP2605** Fluoroprotein foam concentrate is intended for use on Class B hydrocarbon fuels having low water solubility, such as various crude oils, gasoline, diesel fuels, aviation fuels, etc. it is not suitable for use on fuels having appreciable water solubility (Polar solvent), i.e., methyl and ethyl alcohol, acetone and methyl ethyl ketone. This concentrate can be used only with air aspirating type discharge devices.

It can also used with foam compatible dry chemical extinguishing agents without regard to the order of application, to provide even greater fire protection capability.

## Proportioning

**EGY-CP2605** can be used by most conventional foam equipment such as:

- Balance pressure pump proportioning equipment.
- Bladder tank and related proportioners.
- Around –the-pump proportioners.
- Fixed and portable In-line venturi type inductor.
- Fixed or handline nozzle or monitors with fixed induction/pick up tubes.

## Performance

**EGY-CP2605** is measured against specifications and standards such as EN 1568:2008 Part 3 and UL-162.

6% FP # EGY-CP2605

## Foaming Properties

When used with fresh or slat water or water of any hardness at the correct dilution and with most conventional foam making equipment, the expansion ratio will vary depending on the performance characteristic of the equipment. Air aspirating discharge devices produce expansion ratios from 6 to 1 to 12 to 1 depending primarily on type and flow rate. In general, the higher the flow rate the higher the expansion ratio.

Therefore, monitors and foam chambers normally produce higher expansion ratio than foam water sprinkler heads and hand held type nozzles.

Typical expansion ratio for foam chambers are in the range of 5 to 1 to 7 to 1, and for foam water sprinkler heads in the range of 3 to 1 to 6 to 1. Subsurface injection is a special case where generally speaking, expansion ratios of 2 to 1 to 3 to 1 are preferred but up to 4 to 1 is also effective.

## Storage

**EGY-CP2605** Fluoroprotein foam has an operational temperature range of -10°C and +60°C. Limited exposure to temperatures above +60°C does not affect the firefighting performance.

When stored in the packing supplied (polyethylene drums or pails) within the temperature limits specified, or in equipment recommended by the manufacturer as part of the foam system, the shelf life of EGY-CP2605 Fluoroprotein foam concentrate is generally in excess of 10 years.

If the product is frozen during storage or transportation, thawing will render the product completely usable. the factors affecting shelf life and stability for ISS brand foam agents are discussed in details in our technical bulletin for storage recommendation.

## Safety and Handling

See our corresponding "Material Safety Data Sheet"

## Compatibility

There are no specifications or standards which address the subject of compatibility of different manufacturer's brand of fluoroprotein foam concentrates. In an emergency or if the manufacturer has supporting test data to substantiate that the mixer meets the same requirements as the individual component concentrates, they may be mixed together in the same storage vessel. Different types of foam concentrates, i.e., AFFF and fluoroprotein base should not be mixed under any circumstances.

## Ordering Information

Part No.	Container	Weight
EGY-CP2605P	6.6 Gal (25L)	67 lb
EGY-CP2605D	55 Gal (208L)	555 lb

**EGY-CP2605** can be supplied in cans, drums, totes or bulk contact us for bulk delivery details.

## Quality Assurance

**EGY-CP2605** as with all ISS products is subject to very stringent quality controls throughout all stages of production, from incoming raw to the complete product and is manufactured in an ISO 9001:2008 controlled facility quality assurance is therefore guaranteed.

### International Security & Safety Systems Co.

**Factory :** Al Obour Industrial City Block 13040 – Zone A

**Head Office:** 49 Abbas El Akkad St. Nasr City - Cairo - Egypt

**Tel :** +202 ( 24017430 – 22602808 ) **Fax :** +202 ( 22627317 )

www.isssystem.com - info@isssystem.com



الشركة الدولية لأنظمة الأمن والسلامة

المصنع : مدينة العبور المنطقة الصناعية

بلوك : 13040 – قطعة 25

الإدارة : 49 شارع عباس العقاد – مدينة نصر – القاهرة

تليفون : 22602808 – 24017430 فاكس : 22627317